照片家



初始化(部分机型无此步骤)

根据相框上的提示步骤操作:

- 选择语言
- 连接Wi-Fi
- 使用手机相机 / 微信扫描相框二维码下载 【Photist】APP



连接Wi-Fi

- 点击相框屏幕 出现菜单栏
- 点击【Wi-Fi】按钮连接网络



下载【photist】APP

有两种方式下载APP

- 点击【上传】进入二维码页面 使用手机相机 /微信扫描相框二维码下载APP
- 在应用商店中搜索【Photist】 下载安装软件



登陆APP

- 点击【同意】
- 勾选同意隐私政策
- 选择登录方式后点击【登录】



使用APP绑定相框

- 轻触相框屏幕，点击【上传】 进入二维码页面
- 打开【Photist】APP
点击【+】添加设备
点击【扫描二维码】
扫描相框上的二维码绑定
或输入相框上的邀请码绑定



上传照片

- 点击【传送】进入相册
- 选择照片并点击【传送】
点击【开始传输】
- 可通过双指缩放、拖动照片调整显示区域，并根据需要选择横屏或竖屏显示效果
- 调整完成后，点击【开始传输】等待照片上传完成

01 相册模式

相册模式下，设备作为电子相框展示已上传照片，支持浏览与管理





- **上传** 显示设备二维码，使用 Photist APP 扫描并上传照片
- **播放设置** 设置照片轮播的播放方式、切换时长及展示效果
- **管理** 查看相册中的所有照片，并进行照片批量管理
- **编辑** 调整当前照片的大小与显示范围，使照片适配屏幕
- **隐藏** 隐藏当前照片，可在管理页面恢复显示
- **删除** 删除当前选中的照片
- **反馈** 表达对照片的喜好与心情，或将照片收藏

02 日历模式

日历模式下，设备作为电子日历展示日期信息，支持待办提醒





- **上个月 下个月** 点击左右箭头，切换查看上一个月或下一个月
- **今天** 返回当前日期
- **待办事项** 查看或添加待办事项
- **日历样式** 切换日历界面背景，可选择不同的背景效果
- **月/周/天** 切换月视图、周视图和日视图

03 时钟模式

时钟模式下，设备将作为电子时钟展示当前时间，支持闹钟与倒计时设置





- **时钟样式** 切换不同的时钟显示样式
- **闹钟** 设置闹钟时间，到达设定时间后提醒
- **倒计时** 设置倒计时时长，倒计时结束后提醒

04 纯音乐模式

音乐模式下，设备作为蓝牙音响播放音乐，支持动态歌词与音乐频谱显示





- **歌单** 查看相框本地音乐列表和蓝牙音乐列表
- **歌词** 切换不同的歌词显示效果
- **视觉** 切换不同的音乐频谱动效
- **蓝牙**
配对： 点击【配对】按钮，相框提示「已进入配对模式」表示设备已准备好进行蓝牙连接
设备名称： 查看相框的蓝牙设备名称
打开手机蓝牙，搜索相框设备名称并点击连接
连接状态： 查看当前蓝牙连接情况

PHOTIST



Initialization(Not required for some models)

Follow the on-screen instructions.

- Select Language
- Connect to Wi-Fi
- Scan the QR code on the photo frame using your phone camera to download the Photist app.



Connect to Wi-Fi

- Tap the photo frame screen to display the menu bar.
- Tap the 【Wi-Fi】 button to connect to a network.



Download the Photist App

There are two ways to download the app.

- Tap 【Upload】 to display the QR code then scan it using your phone camera to download the app.
- Search for 【Photist】 in your app store and download the app.



Log In to the App

- Tap 【Agree】.
- Check the box to agree to the Privacy Policy.
- Select a login method then tap 【Log In】.



Bind the Photo Frame via the App

- Tap the photo frame screen, then tap 【Upload】 to display the QR code.
- Open the Photist app.
  Tap 【+】 to add a device.
  Tap 【Scan QR Code】 to scan the QR code on the photo frame, or enter the invitation code displayed on the frame to bind it.



Upload Photos

- Tap 【Transfer】 to view your photos.
- Select your photos, tap 【Transfer】 then tap 【Start Transfer】.
- Pinch to zoom and drag the photo to adjust the display area. Choose landscape or portrait orientation as needed.
- Once adjusted, tap 【Start Transfer】 and wait for the photos to finish uploading.

01 Photo Album Mode

In Photo Album Mode, the device displays uploaded photos as a digital photo frame, allowing you to browse and manage them.





- **Upload** Display the device QR code. Scan it with the Photist app to upload photos.
- **Playback Settings** Set the photo slideshow playback mode, transition interval, and display effects.
- **Manage** View all photos in the album and manage multiple photos at once.
- **Edit** Adjust the photo size and display area to fit the screen.
- **Hide** Hide the current photo. It can be restored from the Manage page.
- **Delete** Delete the selected photo.
- **Feedback** Express your feelings about the photo or add it to Favorites.

02 Calendar Mode

In Calendar Mode, the device displays date information and supports task reminders.





- **Previous Month Next Month** Tap the arrows to switch months.
- **Today** Return to Today.
- **To-Do List** View or add to-do items.
- **Calendar View** Change the calendar background style.
- **Month Week/Day** Switch between Month, Week, and Day views.

03 Clock Mode

In Clock Mode, the device displays the current time and supports alarm and countdown settings.





- **Clock Style** Switch between different clock display styles.
- **Alarm** Set an alarm to receive a reminder at the specified time.
- **Countdown** Set a countdown duration and receive an alert when it ends.

04 Music Mode

In Music Mode, the device functions as a Bluetooth speaker and displays synchronized lyrics and a music visualizer.





- **Playlist** View the photo frame's local music library and Bluetooth music list.
- **Lyrics** Switch between different lyric display styles.
- **Visuals** Switch between different music spectrum visualizer effects.
- **Bluetooth**
  Pairing: Tap 【Pair】. When the frame displays Pairing Mode Activated, it is ready to connect via Bluetooth.
  Device Name: View the photo frame's Bluetooth device name.
  Turn on Bluetooth on your phone, search for the photo frame's device name, and tap to connect.
  Connection Status: View the current Bluetooth connection status.